



## Maintenance recommendations for steel distribution cabinets.

### (Atlantic Series)

- ✓ Cabinets and accessories in the Atlantic series meet the requirements of standard **IEC 62208** for metallic enclosures that are to be installed outdoors.
- ✓ Although standard IEC 62208 allows for a degree of **rusting Ri1**, in accordance with ISO 4628-3, and although in practice this degree of rusting does not affect the function or mechanical solidity of the enclosure, maintenance to avoid its aesthetic deterioration and to prolong its useful life is recommended.

### Recommended maintenance:

- ✓ **Frequency:** annual.
- ✓ **Visual inspection:** detection of any harm to the surface such as scrapes or impacts that could have damaged the paint coating.
- ✓ **Initial signs of rust:** due to scrapes, impacts or any other causes.
  - Remove the surface rust.
  - Abrade the surface rust to get rid of it completely.
- ✓ **Cleaning:** clean the affected area with alcohol or an evaporating cleaner.
- ✓ **Paint:** paint the affected surface with a synthetic paint, RAL 9003. (We recommend our white textured paint colour RAL 9003, reference 48343).